




Model - 8018




1) Pre-break scores on display and fold in bottom flaps




2) Roll over sidepanels and lock tabs into slots provided on bottom of display



3) Roll over front flap and lock into place



4) Insert header into back of tray



5) Your finished display

